

Distributed by:




**[www.Jameco.com](http://www.Jameco.com) ♦ 1-800-831-4242**

The content and copyrights of the attached  
material are the property of its owner.

## 2.4 GHz Wireless Booster Amplifier

ITEM NO.: 15-2400BAN



### Caution

It Is Very Important to Follow Under Order For Booster to Function Properly.

### Install

1. Attach the booster to the camera.
2. Attach the antenna to the booster.
3. Power the booster with 9V 600mA-800mA
4. Then, power the camera with 12VDC (use attached adapter).

**Attention:** It is very important to fit together for booster, camera, and camera before plugging in the power. Please plug the power to booster before power the camera.

### Take Off

1. Take off the power of the camera
2. Take off the power of the booster.

### Package

|                   |    |
|-------------------|----|
| 2.1 Booster       | ×1 |
| 2.2 User Manual   | ×1 |
| 2.3 Power Adaptor | ×1 |

### SPECIFICATION

| ITEM             | 15-2400BAN                               |
|------------------|------------------------------------------|
| FREQUENCY (MHz)  | 2400~2500                                |
| INPUT POWER      | 10mW~60mW                                |
| OUTPUT POWER     | 700mW (+/-10%)                           |
| POWER SUPPLY     | Regulator DC 9 V (+/- 0.5V)              |
| CONSUMPTION      | 350mA                                    |
| IMPEDANCE OUTPUT | 50 Ohms                                  |
| OPERATING TEMP.  | 0 TO 50 degrees C. / 40 TO 90 degrees F. |
| DIMENSIONS       | 56mm*51.5mm*20mm                         |
| WEIGHT           | 51g                                      |